

DN495 4G LTE PoC Radio

Quick Start User Guide



DN495 4G LTE PoC Radio

IMPORTANT

By using this product you agree to the terms and conditions of Entel's E-PoC Service License which can be viewed [here](http://www.entel.co.uk/EPoC_LICENSE): www.entel.co.uk/EPoC_LICENSE

INTRODUCTION

The Entel DN495 digital radio is designed for those users who demand the ultimate performance for their business critical communications.

To meet your exact requirements the radio may have been customised by your Entel dealer. These features will be explained in a separate guide issued by the dealer.

PACKING LIST

DN495 PoC radio

Li-ion battery pack

Drop in charger

Spring loaded belt clip

High efficiency antenna

Quick start user guide

OPTIONAL ACCESSORIES

Attaching and removing accessories

- To attach an accessory, remove the accessory cover by unscrewing the locking screw anti-clockwise (store in a safe place).
- Plug the accessory into the socket, then carefully tighten the locking screw clockwise until finger tight (do not overtighten or use any implement).
- To remove an accessory, unscrew the locking screw of the accessory by hand in an anti-clockwise direction. Ensure you re-fit the accessory socket cover so as to protect the socket.
- To prevent corrosion or damage to the accessory connector terminals ensure either a) the accessory cover is fitted or b) an accessory is securely fitted, never leave the terminals exposed.



BATTERY INFORMATION

Battery charging

- Connect the AC adapter to the charger pod and plug in.
- Turn the radio off.
- Insert the battery pack into the charger pod, either with or without the radio attached. The charger LED status light changes to red and charging begins.
- When charging is complete the charger status LED changes from red to green, a fully discharged battery pack will take approximately 2 hours (CNB420E), 3 hours (CNB450E) to re-charge.

A flashing red LED on the charger indicates there is a problem with the battery. Remove the battery from the charger and consult your Entel Dealer.



Battery care

CAUTION

BATTERY PACK PRECAUTIONS

- Do not recharge the battery pack if it is already fully charged. Doing so may reduce the life of the battery pack.
- After charging is complete, remove the battery from the charger. If the power to the charger is turned off and on again, charging will restart and the battery will become overcharged.
- Please ensure the radio is turned off before placing it in the charger and never switch a radio on whilst in the charger.
- Only use Entel branded battery packs and chargers.
- Do not short the battery terminals or dispose of the battery in a fire.
- Do not charge the radio and/or battery pack if they are wet.

DANGER

DO NOT DISASSEMBLE OR MODIFY THE BATTERY IN ANY WAY!

Your Entel battery pack incorporates a safety circuit to avoid danger, if the safety circuit is damaged or bypassed, or the battery cells are damaged directly, they may generate extreme heat, smoke, rupture and emit flames.

REPAIR & MAINTENANCE

Repair and maintenance of this product can only be carried out by Entel. Any damage to the anti-tamper seal will invalidate the product approval. Should you have any difficulties in operating this product please contact your Entel Dealer for support.

NAV KEY DISPLAY



1. On/Off/Volume control. Rotate clockwise to turn on and increase volume. Rotate anti-clockwise to reduce volume & turn off.
2. Group (Channel) Control
3. Accessory socket
4. Push To Talk (PTT) button, press to speak and release to listen
5. Dealer programmable buttons (ask your dealer for more information)
6. LED indicator
 - Amber steady - Booting up
 - Amber / Red alternating - Not connected
 - Amber flash every 5-seconds - Radio in standby
 - Red steady - Transmitting
 - Green steady - Receiving
 - Amber rapid flash - In 1-2-1 call
 - Amber double flash - Calling / being called
 - Green rapid flash - Call hang time
 - Red double flash - Low battery
 - Red fast flash - Error
7. Info button
8. Navigation key
9. Microphone
10. Group (Channel) list*
11. User contact list*
12. Menu*
13. Call button*
14. End-call button*

* If enabled by your Dealer

PREPARING YOUR RADIO FOR USE

Attaching/removing the antenna



1. To attach, carefully align the antenna with the socket. Screw in the antenna and clockwise (taking care not to cross the thread) until it is seated firmly (A).
2. To remove, unscrew the antenna anti-clockwise (B).

Attaching/removing the battery pack



1. To attach (C), locate the pegs on the bottom of the battery into the slots on the radio and pull the 2 latches downwards, carefully pushing the battery into the radio. Release the latches ensuring the battery is fully attached.
2. To remove (D), pull down the 2 latches and carefully pull the battery away from radio.

SWITCHING ON, RECEPTION AND SWITCHING OFF

1. To switch on rotate the on/off/volume control (1) on the top of the radio clockwise, you will hear a click from the control.
2. When the radio has passed its diagnostic tests, it will emit a fanfare tone.
3. The radio will enter standby mode. This is indicated by the LED flashing Amber once every 5 seconds, indicating the radio is ready for use.
4. Adjust the volume control (1) to select the desired volume level.
5. Using the Group (Channel) Control (2) ensure that you have the correct Group selected.
6. When receiving a valid signal the LED will illuminate steady green and audio will be emitted from the radio's speaker or audio accessory (if attached).
7. When finished using the radio, switch off by turning the on/off/volume control (1) counter clockwise until it clicks and the radio will be switched off.

DECLARATION OF CONFORMITY

Hereby, Entel UK Limited Declares that the radio equipment type DN495 is in compliance with Directive 2014/53/EU and Radio Equipment Regulations 2017.

The full text of the relevant declaration of conformity is available at the following internet address:

EU www.entel.co.uk/red
UK www.entel.co.uk/UKCA

FCC APPROVAL

Contains FCC ID: XMR201911SC20AL
Contains IC: 10224A-201707SC20A

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 Canada.

The product shall only be put into service after it has been professionally configured by a specialist radio communications dealer for the EU member state or geographical area it is intended to be operated within.

Intended country of use

	AT	BE	BG	CH	CY	CZ	DE	DK	EE
	ES	FI	FR	EL	HR	HU	IE	IS	IT
	LI	LT	LU	LV	MT	NL	NO	PL	PT
	RO	SE	SI	SK	TR	UK(NI)			

